Richmond Refinery LPS Alert – Safety

FCC Bottoms System - Operator Injury





IMPACT #: 503

Location: FCC

Contact Information:

Rick Smith 242-4268 RickSmith@chevron.com

Reference: Information

Always remember to do your LPSA - because we care about you!

This document is intended for company workforce only. Nothing herein should be construed as a legal determination of causation or responsibility. The company makes no representations or warranties, express or implied, about the thoroughness, accuracy, or suitability of use by others of any of the information contained herein.

Incident Description:

Two FCC Operators were splashed with a mixture of fractionator bottoms and steam/condensate during the planned FCC turnaround cleanup activities on Sunday night (October17th). One employee received injuries that required first aid treatment by the clinic and was released back to work. The other employee sustained 1st and 2nd degree burns on his lower legs. He is currently receiving medical treatment at the Saint Francis burn unit in San Francisco.

The event occurred while the operators were removing a coke bucket/strainer from a coke/catalyst knock-out pot on the main fractionators bottoms circulation system.

A TapRooT investigation is in progress.

Immediate Actions Taken:

- 1. A safety stand-down was held after the system was secured.
- 2. Other turnaround areas are being reviewed to ensure we don't have exposures to a similar incident.

What You Can Do:

- Perform a LPSA before each task think about "line of fire", obstructions to movement, and other hazards that you might have become accustomed to. Assess those hazards and take the necessary steps to ensure the job can be performed safely.
- 2. Its worth noting that you can increase thermal protection by wearing full length undergarments (like cottons jeans and a long sleeve cotton shirt) which results in a layering effect that produces an "air gap". Wearing a Nomex jacket on top of your coveralls also provides additional thermal protection. Clothing worn under your coveralls should be of natural materials (cotton, silk or wool).

Ask yourself if your working conditions allow you to use this layer effect for your protection without any unintended consequences (e.g. over heating).

